



Your Global Automation Partner

TX800L

PLC and IIoT Edge Controller

Instructions for Use

Table of Contents

1	About these instructions	4
1.1	Target groups	4
1.2	Explanation of symbols	4
1.3	Other documents	4
1.4	Feedback about these instructions	4
2	Notes on the product	5
2.1	Product identification	5
2.1.1	Type label	5
2.1.2	Type code	6
2.2	Scope of delivery	6
2.3	Turck service	6
2.4	Software licenses	7
3	For your safety	8
3.1	Intended use	8
3.2	General safety notes	8
3.3	Notes on Ex protection	8
3.4	Note on explosion protection (USA and Canada only)	8
3.5	Conditions resulting from Ex approvals for use in Zone 2	9
4	Product description	10
4.1	Device overview	10
4.2	Properties and features	10
4.3	Functions and operating modes	11
4.4	Accessories	11
4.4.1	Plug-in extension modules	11
4.4.2	Power supply	11
5	Installing	12
5.1	Installation instructions	12
5.2	Mounting the device on a DIN rail	12
5.3	Installing plug-in modules	12
5.4	Grounding the device	13
6	Connecting	14
6.1	Connecting the power supply	15
6.2	Connecting external devices to the serial interface	16
6.3	Connecting plug-in modules	17
6.3.1	Slot assignment – CAN port	18
6.3.2	Slot assignment – serial interfaces	18
7	Commissioning	19
7.1	Charging the battery	19
7.2	Initial commissioning	19
7.2.1	User management	19
7.3	Web server login	20
7.4	Setting the IP address	21
7.4.1	Setting the IP address via the web server	21
7.4.2	Setting the IP address via Turck Service Tool	22

- 7.4.3 Setting the IP address via TAS (Turck Automation Suite) 23
- 7.5 Programming with CODESYS 24**
 - 7.5.1 Supported protocol functions 24
 - 7.5.2 Access to the CODESYS WebVisu 24
- 7.6 Programming with TX VisuPro 25**
 - 7.6.1 Transferring TX VisuPro to the device..... 25
- 8 Configuring 26**
 - 8.1 Configuring the system settings..... 26
- 9 Operating..... 29**
 - 9.1 LED displays 29
- 10 Troubleshooting..... 30**
- 11 Repair 31**
 - 11.1 Returning devices 31
- 12 Disposal..... 31**
- 13 Technical data..... 32**
- 14 Appendix: approvals and markings 34**
- 15 Turck branches — contact data 35**

1 About these instructions

These instructions describe the setup, functions and use of the product and help you to operate the product according to its intended purpose. Read these instructions carefully before using the product. This will prevent the risk of personal injury and damage to property. Keep these instructions safe during the service life of the product. If the product is passed on, pass on these instructions as well.

1.1 Target groups

These instructions are aimed at qualified personnel and must be carefully read by anyone mounting, commissioning, operating, maintaining, dismantling or disposing of the device.

When operating the device in a hazardous area, the user must have a working knowledge of explosion protection (IEC/ EN 60079-14, etc.).

1.2 Explanation of symbols

The following symbols are used in these instructions:



DANGER

DANGER indicates a hazardous situation with a high level of risk, which, if not avoided, will result in death or serious injury.



WARNING

WARNING indicates a hazardous situation with a medium level of risk, which, if not avoided, will result in death or serious injury.



CAUTION

CAUTION indicates a hazardous situation with a medium level of risk, which, if not avoided, will result in moderate or minor injury.



NOTICE

CAUTION indicates a situation which, if not avoided, may cause damage to property.



NOTE

NOTE indicates tips, recommendations and important information about special action steps and issues. The notes simplify your work and help you to avoid additional work.



MANDATORY ACTION

This symbol denotes actions that the user must carry out.



RESULT OF ACTION

This symbol denotes the relevant results of an action.

1.3 Other documents

The following additional documents are available online at www.turck.com

- Data sheet
- Quick Start Guide
- Declarations of conformity (current version)
- Approvals

1.4 Feedback about these instructions

We make every effort to ensure that these instructions are as informative and as clear as possible. If you have any suggestions for improving the design or if some information is missing in the document, please send your suggestions to techdoc@turck.com.

2 Notes on the product

2.1 Product identification

These instructions apply to the following IIoT edge controllers:

- TX800L-P3WV01 (ID: 100046998)

2.1.1 Type label

The type label is located on the back of the device.





Fig. 1: Type label TX800L

Type designation	TX800L
ID	100046998
Year/week of production	A2347
Internal version ID of the product	V.: ...
Serial number	S.N.: AA...AA

2.1.2 Type code



2.2 Scope of delivery

The delivery consists of the following:

- TX800
- Power supply connector
- Connector for serial interface
- Quick Start Guide

2.3 Turck service

Turck supports you in your projects — from the initial analysis right through to the commissioning of your application. The Turck product database at www.turck.com offers you several software tools for programming, configuring or commissioning, as well as data sheets and CAD files in many export formats.

For the contact details of our branches worldwide, please see page [► 35].

2.4 Software licenses

This product uses software-packages from third-party sources which are used within the scope of the licenses listed in the web server:

You can view the licenses valid for the product at the following link:

<http://<device IP address>/license.html>

Source code for the open-source packages included in this product can be requested at:

Hans Turck GmbH & Co. KG
Attn. Legal Department
Witzlebenstraße 7
D-45472 Mülheim an der Ruhr
or by e-mail to open.source@turck.com.

Your request should include:

1. the name of the covered binary
2. the version number of the Turck product containing the covered binary
3. your name
4. your company name (if applicable)
5. your return mailing and email address (if available)

We may charge you a nominal fee to cover the cost of the media and distribution. Your request must be sent within three (3) years after delivery of the product or as long as we offer spare parts or customer support for this product model.

3 For your safety

The product is designed according to state of the art technology. Residual hazards, however, still exist. Observe the following safety instructions and warnings in order to prevent danger to persons and property. Turck accepts no liability for damage caused by failure to observe these safety instructions.

3.1 Intended use

The IIoT edge controllers of the TX800 family are used to control, operate and monitor machine processes. The devices are used for control tasks in automation applications in the IIoT environment.

The IIoT edge controller collects data in the application, pre-processes it locally, filters it and sends relevant data to the internet or to a central IIoT platform or cloud.

The device must only be used as described in these instructions. Any other use is not in accordance with the intended use. Turck accepts no liability for any resulting damage.

3.2 General safety notes

- The device must only be fitted, installed, operated, parameterized and maintained by trained and qualified personnel.
- Only use the device in compliance with the applicable national and international regulations, standards and laws.
- The programmable devices can be used to control machines. Changes to system and network settings or the controller program may cause undefined states in the controlled machine. Changes must only be carried out if the controlled machine is in the safe stop state and the device is isolated from the machine.
- Change the default password of the integrated web server after the first login. Turck recommends the use of a secure password.

3.3 Notes on Ex protection

- Observe national and international regulations for explosion protection.
- When using the device in Ex areas, the user must have knowledge of explosion protection (IEC/EN 60079-14 etc.).
- Only use the device within the permissible operating and ambient conditions (see certification data and Ex approval specifications).
- This device is an open device and must be installed in a housing suitable for the environment, so that the inner part of the device is only accessible by means of a tool.
- Do not disconnect the device in an ignitable atmosphere when energized.
- Do not open the device when energized.
- Do not remove Ethernet connections, USB devices and SD cards in an ignitable atmosphere.
- Do not remove the battery in an ignitable atmosphere.
- Switch-off the device before replacing or wiring extension modules.

3.4 Note on explosion protection (USA and Canada only)

- The device is suitable for the use in Class I, Division 2, groups A, B, C and D hazardous locations or for the use in non-hazardous locations.
- The Power, input and output (I/O) wiring has to be done in accordance with Class I, Division 2 and in accordance with the authority having jurisdictions. For U.S. in accordance with Article 501.10 (B) of the National Electrical Code, NFPA 70 and for Canada in accordance with Section 18-1J2 of Canadian Electrical Code.
- Use only components that meet Class I, Division 2 certification.
- Disconnect the device from the power supply before replacing or connecting plug-in modules.
- Do not disconnect the device in an ignitable atmosphere when energized.

3.5 Conditions resulting from Ex approvals for use in Zone 2

Special conditions of use

- Only use the device in an area of not more than pollution degree 2 as defined in EN IEC 606641.
- The equipment shall be installed through an end-equipment enclosure that provides a minimum ingress protection of IP54 in accordance with EN IEC 60079-0, suitable for the applicable gas group, temperature classification and ambient temperature range.
- Transient protection shall be provided that is set at a level not exceeding 140 % of the peak rated voltage value at the supply terminals to the equipment.
- Observe the permissible ambient temperature depending on the temperature class [► 34].

4 Product description

three Ethernet ports are available for the connection to Ethernet.

The serial port is used to communicate with a PLC or with field devices with RS232 or RS485 interface. Plug-in modules with different functions (digital and analog I/Os, CAN master, PROFIBUS-DP slave, RS232 and RS485 interface, mobile communication and WLAN modem, etc.) can be connected via the extension slots. A USB host port and an SD card slot are provided for using external storage media.

The device is designed in protection class IP20.

The device of the TX800 device family are designed as CODESYS-V3-PLC and IIoT edge controllers.

4.1 Device overview




Fig. 2: Dimensions TX800L

4.2 Properties and features

- Gateway function with OPC UA Server and Client (with TX VisuPro)
- Safe connection to Turck Cloud with complete network isolation
- MQTT for connecting all common cloud systems (with TX VisuPro)
- CODESYS V3 PLC runtime with selection of the most important I/O protocols
- CODESYS V3 WebVisu or TX VisuPro WebVisu
- TX VisuPro HMI protocols for connecting control systems of all common manufacturers
- Optional extension modules for I/Os and further communication interfaces

4.3 Functions and operating modes

The CODESYS V3 PLC of the TX800 devices has the functions PROFINET controller, EtherCAT MainDevice, EtherNet/IP scanner and Modbus TCP as well as Modbus RTU client. Additionally the devices of the TX800 IIoT edge controller can be used as PROFINET device, Modbus TCP as well as Modbus RTU server.

The devices combine all functions of a PLC with the functions and interfaces of the TX VisuPro software.

Additional functions

- Ethernet TCP/IP or UDP/IP communication
- OPC UA server (with CODESYS or TX VisuPro)
- OPC UA client and MQTT (with TX VisuPro)
- Serial communication via RS232, RS485 and RS422

4.4 Accessories

4.4.1 Plug-in extension modules

ID	Type	Description
6828210	TX-CAN	CAN interface
6828203	TX-IO-DX06	■ 4 digital inputs, 24 VDC, pnp ■ 6 digital outputs, 24 VDC, 0.5 A, pnp ■ 1 relay output, NO
6828201	TX-IO-XX03	■ 20 digital inputs, 24 VDC, pnp ■ 12 digital outputs, 24 VDC, 0.5 A, pnp ■ 4 analog inputs, U, I, RTD, TC ■ 4 analog outputs, U, I
100002598	TX-RS485	Serial interface for RS485/RS422 communication
100002599	TX-RS232	Serial interface for RS232 communication
100004786	TX-EXTEND	Bus extension, electromechanical adapter for the use of the plug-in module TX-IO-XX03
100025179	TX-LTE-WLAN	Wireless modem ■ Mobile radio: 2G, 3G, 4G ■ WLAN: IEEE 802.11a, IEEE 802.11b, IEEE 802.11g, 2.4 GHz and 5 GHz
100010167	TX-DP-S	PROFIBUS-DP slave, 12 Mbaud

4.4.2 Power supply

ID	Type	Description
100002938	TX-PSC	TX power supply onnector

5 Installing



NOTICE

Operation in residential and commercial areas

Electromagnetic disturbances!

- ▶ When operating the devices in residential and commercial areas: observe the measured values according to IEC 61000-6-3.

5.1 Installation instructions

- The equipment shall only be used in an area of not more than pollution degree 2, as defined in IEC/EN 60664-1.
- The equipment shall be installed in an enclosure that provides a degree of protection not less than IP 54 in accordance with IEC/EN 60079-0.

5.2 Mounting the device on a DIN rail

- ▶ Insert the device into the top-hat rail from below and turn it upwards until the upper locking hook engages on the top-hat rail.
- ▶ Mount the device in a position that ensures ventilation of the device. Do not cover the ventilation slots.

5.3 Installing plug-in modules




Fig. 3: Installing plug-in modules
(e. g. TX-CAN, TX-IO-DX06)




Fig. 4: Installing plug-in modules
(e. g. TX-IO-XX03)

5.4 Grounding the device

The unit has to be grounded.

- ▶ Ground the device via the grounding screw on the back of the housing or via terminal 3 on the power supply connection.
- ▶ Observe the minimum cable cross-section of 1.5 mm² for the grounding connection.

General notes for device grounding

- ▶ All the electronic devices in the control system must be properly grounded.
- ▶ Carry out grounding according to the applicable regulations.
- ▶ Ground the device to minimize noise effects from electromagnetic interference.

Grounding the power supply

The power supply circuit may be floating or grounded.

- ▶ To ground the supply circuit, connect the ground wire to the protective earth as shown in the following figure (dotted line).
- ▶ If the supply circuit is not grounded, the unit itself is internally connected to ground (1 MΩ resistor with 4.7 nF capacitor connected in parallel).
- ▶ The power supply must have double or reinforced insulation.




Fig. 5: Power supply – wiring

6 Connecting



DANGER

Ignitable atmosphere

Explosion by ignitable sparks

- ▶ Do not disconnect the device in an ignitable atmosphere when energized.
- ▶ Disconnect the device from the power supply before replacing or connecting modules.

- ▶ Observe notes on explosion protection.
- ▶ Provide transient protection at the supply terminals set to a maximum of 140 % of the peak value of the rated voltage.
- ▶ Ensure that the power supply is of sufficient capacity to operate the device.




Fig. 6: Connectors TX800L

Connector	Description
1	USB ports V2.0, max. 500 mA
2	Ethernet port 2 (10/100 Mbps)
3	Ethernet port 1 (10/100 Mbps)
4	Serial interface
5	Ethernet port 0 (10/100/1000 Mbps)
6	Power supply
7	2 extension slots for plug-in modules
8	SD card slot

6.1 Connecting the power supply

- ▶ Connect the device to the voltage supply according to the following figure.




Fig. 7: Power supply connector TX...



NOTE

The power connector is part of the scope of delivery and can be ordered as spare part Accessories.

6.2 Connecting external devices to the serial interface

The serial port is used to communicate with a PLC or with another type of device. The following standards are available at the serial interface: The type of serial interface is determined in the programming software. The connection cable must be selected to match the device to be connected.

- Connect the serial devices according to the pin assignment.




Fig. 8: RS232 connection




Fig. 9: RS485 connection




Fig. 10: RS422 connection



NOTE

To operate in RS485, pins 1 and 2 as well as pins 3 and 4 must be connected externally.

6.3 Connecting plug-in modules

The TX800 IIoT edge controller allow the use of several optional in modules. Several module configurations are possible.




Fig. 11: Expansion slots for plug-in modules

Slot2 and Slot4 are available only if the plug-in module has bus extension connector.

Each slot has three communication channels:

- 1 serial interface
- 1 CAN interface
- 1 SPI interface
- 1 USB interface



NOTE

It is not possible to stack two modules that are using the same type of interface.

The following table shows, which plug-in module and how many plug-in modules can be used at which device. The column max. modules refers to the max. number of modules which can be plugged into the HMI (all slots).

Module	Application	Max. number of modules	Interface type/ communication interface	Bus extension connector
TX-CAN	CAN	2	CAN	Yes
TX-RS485	RS485/RS422		Serial	Yes
TX-RS232	RS232		Serial	Yes
TX-IO-DX06	Compact I/O	1	SPI	No
TX-IO-XX03	Multifunction I/O		SPI	No
TX-DP-S	PROFIBUS-DP slave	1	SPI	No
TX-LTE-WLAN	Wireless modem		USB	Yes
TX-EXTEND	Expansion module	2	None	Yes

6.3.1 Slot assignment – CAN port

Physical interface	CODESYS parameter „network“
Slot 1	Network 0
Slot 2	Network 0
Slot 3	Network 1
Slot 4	Network 1

6.3.2 Slot assignment – serial interfaces

Physical interface	CODESYS parameter “Device/In- terface Parameter”	CODESYS parameter “Modbus COM/COM Port”
local serial COM port	Mode COM1	COM Port 1
Slot 1	Mode COM2	COM Port 2
Slot 2	Mode COM2	COM Port 2
Slot 3	Mode COM3	COM Port 3
Slot 4	Mode COM3	COM Port 3

Slot 1 to Slot 4 refer to the extension slots on the rear of the device.

7 Commissioning

7.1 Charging the battery

The device is equipped with a rechargeable lithium battery, which is not user replaceable.

The following information is maintained by the battery:

- Hardware real-time clock (date and time)
 - ▶ Charge the battery for at least 48 hours before using the device for the first time.

When the battery is fully charged, it guarantees data backup at 25 °C for three months.

7.2 Initial commissioning

The IP address of Ethernet port ETH1 is set to 192.168.1.254 by default. The web server (System Settings) can be opened via this IP address using a web browser, the Turck Automation Suite (TAS) or the Turck Service Tool.

7.2.1 User management

To prevent unauthorized access to the system, it is necessary to enter secure passwords for the two users "user" and "admin" during initial commissioning.

Passwords must meet the following minimum requirements:

- at least 8 characters
 - at least 1 lowercase and 1 uppercase letter
 - at least 1 number
 - at least 1 special character
- ▶ Enter, confirm and save the password for the user "user".
 - ▶ Enter, confirm and save the password for the user "admin".

The screenshot shows a web browser window titled "Authentication". In the top right corner, there are links for "RELOAD" (with a circular arrow icon) and "ADMIN" (with a key icon). A yellow banner at the top states: "Password change is required at first access. NOTE: system will reboot upon completion". Below this, the main heading is "[1/2] Choose a password for user 'user'". On the left, there are two input fields: "New Password" and "Confirm Password", both containing masked characters (dots). Below the "Confirm Password" field is a button labeled "Change Password" with a gear icon. On the right side of the form, there is a list of requirements: "Passwords are required to include:" followed by four bullet points: "At least 8 characters in total", "At least one lower case and one upper case letter", "At least one numeric character", and "At least one special character (eg. # ! @ ?)".

Fig. 12: Assigning admin password

⇒ The device performs a restart.

7.3 Web server login

- ▶ Open the web server using the device's IP address.
- ▶ Connect via `https://IP`.
IP = current IP address of the TX... device
- ▶ Log on to the device as administrator:
Default user: admin
Default password: admin

If the simple link causes a conflict with an already active WebVisu application, the system settings can also be accessed directly via the following link:

`https://192.168.1.254/machine_config`

Username: admin

Password: admin

The IP address 192.168.1.254 is the IP address at Ethernet port ETH1 in the delivery state. If the IP address for Ethernet port ETH1 has already been changed, then the current IP address of the port is entered here.

7.4 Setting the IP address

The IP addresses of the device can be set via the web server of the device. The IP address via which the device is connected to the PC via Ethernet can also be set via the Turck Service Tool or via the Turck Automation Suite (TAS).

7.4.1 Setting the IP address via the web server

- ▶ Log in to the device's web server as described under "Web server login".
- ▶ Edit the network setting via **System Settings** → **Network** → **Edit**.




Fig. 13: Webserver – system settings

- ▶ Set the IP address, the subnet mask, etc. under **Network interface** and save the changes.




Fig. 14: Webserver – network interface

7.4.2 Setting the IP address via Turck Service Tool

- ▶ Connect the device to the PC via the Ethernet interface.
- ▶ Open Turck Service Tool.
- ▶ Click **Search** or press [F5].




Fig. 15: Turck Service Tool – home screen

⇒ Turck Service Tool shows the connected devices.



NOTE

Clicking the device's IP address opens the web server.




Fig. 16: Turck Service Tool – found devices

- ▶ Click on the desired device.
- ▶ Click **Change** or press [F2].
- ▶ Change the IP address and the net mask, if necessary.
- ▶ Accept the changes with **Set in device**.

Fig. 17: Turck Service Tool – changing the IP configuration

7.4.3 Setting the IP address via TAS (Turck Automation Suite)

- ▶ Connect the device to the PC via the Ethernet interface.
- ▶ Open Turck Automation Suite in the web browser.
- ▶ Select **Device list** → **Network** and click **Scan network**.




Fig. 18: Turck Automation Suite: scanning the network

⇒ The Turck Automation Suite shows the connected devices.

Actions	Device type/feature	PN device name	IP address	Adapter address	Address mode	MAC address	Subnet mask/Gateway	Version
[Icon]	TX-PRO-1000		192.168.145.7	192.168.145.11	PGM-DHCP	00:07:46:25:09:3C	255.255.255.0 / 0.0.0.0	1.3.83
[Icon]	TX-PRO-1000	AB	192.168.145.97	192.168.145.11	PGM-DHCP	00:07:46:89:24:42	255.255.255.0 / 0.0.0.0	3.3.6.1
[Icon]	TX-PRO-1000	A	192.168.145.121	192.168.145.11	PGM-DHCP	00:07:46:08:1D:13	255.255.255.0 / 0.0.0.0	3.5.0.0
[Icon]	TX-PRO-1000	A	192.168.145.111	192.168.145.11	PGM-DHCP	00:07:46:FF:A9:91	255.255.255.0 / 0.0.0.0	3.4.2.0

Fig. 19: Turck Automation Suite: found devices

- ▶ Click on the desired device.
- ▶ Click **Edit device**
- ▶ Change the IP address and, if necessary, the default gateway and subnet mask in the **network settings** window.
- ▶ Accept the changes with **apply**.

Fig. 20: Turck Automation Suite: Change network settings

7.5 Programming with CODESYS

The devices are delivered with a pre-installed CODESYS runtime.

The CODESYS software as well as the CODESYS package for the devices can be downloaded from www.turck.com.

Prerequisites

- CODESYS (≥ V 3.5.18.0) and the package "TXxxx HMI/PLC series" for the device have to be installed on a PC computer running Microsoft Windows.

7.5.1 Supported protocol functions

Protocol	Controller/client	Device/server
PROFINET	Yes	Yes
EtherNet/IP	Yes	-
Modbus TCP	Yes	Yes
Modbus RTU	Yes	Yes
CANopen	Yes	-
EtherCAT	Yes	-
OPC-UA	-	Yes

7.5.2 Access to the CODESYS WebVisu

The CODESYS WebVisu is accessed via port 8085:

<http://<<IP address>>:8085/webvisu.htm>

Example:

<http://192.168.1.40:8085/webvisu.htm>

7.6 Programming with TX VisuPro

Prerequisites

- For programming the HMI/PLCs with TX VisuPro, the software tool has to be installed on a PC computer running Microsoft Windows.
- If the visualization of TX VisuPro is to be used instead of the CODESYS-TargetVisu, the TX VisuPro runtime has to be installed first.
- Before installing the TX VisuPro runtime, the existing CODESYS runtime has to be deleted.
 - ▶ To delete the currently installed runtime, run the following command:
System Settings → Management → Data → Clear



NOTE

In addition to the runtime, the "delete" command also deletes all other application data such as the CODESYS application and any log files that may have been created. Alternatively, the CODESYS runtime can be deactivated in tap-tap mode. However, Turck recommends deleting the runtime completely.

Deactivate alternative CODESYS runtime (not recommended)

- ▶ Tap-Tap-Mode [▶ 26] → **Startup sequence** → sign on as „admin“ and move **CODESYS-App** from the **Boot Sequence** area to **Installed Aps**.

7.6.1 Transferring TX VisuPro to the device

There are two options to transfer a TX VisuPro runtime project to a device:

- Via Ethernet
- Via a USB stick

Project transfer via Ethernet

- ▶ Connect the HMI device to the computer with an Ethernet network.
- ▶ Execute the command **Run/Download** in TX VisuPro. You may have to ensure that the proper firewall policy has been configured in the computer to allow TX VisuPro to access the network.

Project transfer via a USB stick

- ▶ Create an update package with TX VisuPro and copy it to a USB stick.

8 Configuring

The devices have an integrated a web server for configuring the system. The user interface is based on HTML pages accessible via port 443 using a Web browser (Firefox V.79, Chrome V.44 or higher). Alternatively, the system settings can be called and operated via a VNC client. To use the VNC client, the VNC service must be activated in the system settings.

The initial commissioning must be carried out via access by web server see "Web server-Login" [► 20].

8.1 Configuring the system settings

The available options can be selected from the navigation menu on the left side of the screen.

Fig. 21: System settings

Two operating modes are available for the system settings:

Mode	Usage
User mode	■ Device with TX VisuPro runtime ■ Device in delivery state
System Mode	In addition to the options in user mode, the system mode includes additional commands for system upgrade and recovery. ■ Device without TX VisuPro runtime ■ Device with software error

Edit system settings in user mode

Status device	Description
Factory default status	▶ Open the System Settings .
TX VisuPro runtime running	▶ Press and hold the unused area of the touch screen for at least 2 s. ▶ Open the context menu and select System Settings .

Edit system settings in System mode

Status device	Description
Standard state	If no TX VisuPro runtime is running on the device: User mode ▶ Open the System Settings. System Mode ▶ Without TX VisuPro runtime: Restart the device via Restart → Config. Restart OS. ▶ With TX VisuPro runtime: Open the context menu and select System Settings. ▶ To recall the context menu: Press and hold the unused area of the touch screen for at least 2 s. ▶ Restart the device via Restart → Config. Restart OS.
Recovery operation	If the device is not responsive, use the so-called "tap-tap" procedure: ▶ Touch the surface of the touch screen several times with a typing frequency of at least 2 Hz immediately after switching on the device. ⇒ When the sequence is detected, the message "Tap Tap detected, Going to Config Mode" will appear on the display.

The basic settings for the device are made in the system settings.

Setting	Description
Localization	Configuration of the language used for the "system settings" menu.
System	Information about platform, status and timers ("like System on time, "backlight on time")
Logs	Activating and exporting persistent log for BSP
Date & Time	Date and time, including time zone and NTP Server
Network	Configuration to the IP address of the Ethernet interface and all other network settings like DNS, Gateway, DHCP, Host name, routing and bridging.
Security	Contains passwords and certificates that are required by the applications used.
Applications	Listing and managing the applications loaded on the HMI. The "App management" is used to load new applications, update or remove applications that are already installed and define the application start sequence.
Services	Activate/deactivate services (e.g. OpenSSH server, bridge, cloud, router, SNMP, logging)

Setting	Description
Management	Update of BSP components (Main OS, Config OS, Boot loader, XLoader), check for partitions consistence, update of splash screen, information about usage and size of partitions. The update of Main OS is available only in System Mode, the update of Config OS is only in User Mode.
Fonts	Shows the currently used fonts and enables the installation of user-defined fonts.
Authentication	Configuration of the password for the administrator ("admin") and for the standard user ("user"). The administrator has full access to the system settings (updates of the BSP and other system components). The standard user has some restrictions.
Restart	Restarts the device By default, the device is restarted in user mode via the "Main OS" option. The "Configuration OS" option restarts the device directly in System Settings in System Mode.

9 Operating



DANGER

Changing components

Explosion hazard – Suitability for Class I, Division 2 possibly impaired

- ▶ When replacing components, make sure that the suitability of the device for Class I, Division 2 is not affected.
- ▶ Only use components that are suitable for use in Class I, Division 2.
- ▶ If necessary, take measures to restore suitability for Class I, Division 2.

9.1 LED displays

The device has the following LED displays:

- Status of the Ethernet ports

LED orange (left LED)	Meaning
Off	No Ethernet connection
On	Ethernet connection established
LED green (right LED)	Meaning
On	No data transfer
Flashing	Data transfer

10 Troubleshooting



DANGER

Ignitable atmosphere

Explosion by ignitable sparks

- ▶ Do not disconnect the device in an ignitable atmosphere when energized.
- ▶ Disconnect the device from the power supply before replacing or connecting modules.

If the device does not function as expected, first check whether ambient interference is present. If there is no ambient interference present, check the connections of the device for faults.

If there are no faults, there is a device malfunction. In this case, decommission the device and replace it with a new device of the same type.

If the device does not work as expected, proceed as follows:

- ▶ Exclude environmental disturbances.
- ▶ Check the connections of the device for errors.
- ▶ Check device for parameterization errors.

If the malfunction persists, the device is faulty. In this case, decommission the device and replace it with a new device of the same type.

11 Repair

The device is not intended for repair by the user. The device must be decommissioned if it is faulty. Observe our return acceptance conditions when returning the device to Turck.

11.1 Returning devices

If a device has to be returned, bear in mind that only devices with a decontamination declaration will be accepted. This is available for download at

<https://www.turck.de/en/return-service-6079.php>

and must be completely filled in, and affixed securely and weather-proof to the outside of the packaging.

12 Disposal

The device is equipped with a rechargeable lithium battery, which is not user replaceable.

- For disposal, open the back of the device and remove the battery.



The device the lithium battery must be disposed of properly in accordance with WEEE Directive 2012/19/EU and does not belong in normal household waste.

13 Technical data

Device	TX800L-P3WV01
ID	100046998
System	
CPU	64 bit RISC, quad core, 1.6 GHz
Operating system	Linux RT
Flash	4 GB (eMMC pSLC)
RAM	2 GB
Expansion memory	USB/SD card
Real Time Clock	Yes (battery-backed)
Accuracy RTC (at 25 °C)	< 100 ppm
Buzzer	Yes
SPS data	
Programming	CODESYS V3
Programming languages	IEC 61131-3 (IL, LD, FBD, SFC, ST)
Programming interface	Ethernet
Program memory	20 MB
Non-volatile memory	63 kByte
Interfaces	
Ethernet ports	1 × 10/100/1000 Mbit 2 × 10/100 Mbit
Serial ports (configurable)	1 × RS232/RS485/RS422
USB Host port	2 × Host V2.0, max. 500 mA
SD card	Yes
Extension slot (plug-in)	2
■ Max. number of plug-in modules	4
Power supply	
Nominal value	24 VDC (SELV or Class 2)
Admissible voltage range	18...32 VDC
Current consumption at 24 VDC	Max. 0.5 A
Dimensions	
Housing (H × D)	174 × 144 mm
Width on DIN rail	44 mm
Weight	0.7 kg



NOTE

For applications requiring compliance with EN 61131-2 and specifically in reference to 10 ms voltage dips, the minimum power supply voltage is 18 VDC.

Degree of protection		
Complete device	IP20	EN 60529
Environmental conditions		
Operating temperature (surrounding air temperature)	-20...+60 °C (Temperature Class T4, vertical installation) 0...50 °C (Temperature Class T5) installed with plug-in module TX-IO-XX03	EN 60068-2-14
Storage temperature	-20...+70 °C	EN 60068-2-1 EN 60068-2-2 EN 60068-2-14
Operating and storage humidity	5...85 % RH, non condensing	EN 60068-2-30
Vibrations	5...9 Hz, 7 mm _{p-p} 9...150 Hz, 1 g	EN 60068-2-6
Shock	± 15 g, 11 ms, 3 pulses per axis	EN 60068-2-27
Electromagnetic Compatibility (EMC)		
Radiation interference	Class A	CISPR 22, CISPR 16-2-3
Immunity		
Electrostatic discharge	8 kV (air electrostatic discharge) 4 kV (contact electrostatic discharge)	EN 61000-4-2
Radiation, high frequency, electromagnetic fields	80 MHz...1 GHz, 10 V/m 1.4 GHz...2 GHz, 3 V/m 2 GHz...2.7 GHz, 1 V/m	EN 61000-4-3
Burst	± 2 kV DC power port ± 1 kV signal line	EN 61000-4-4
Overvoltage	± 0,5 kV DC power port (line to earth) ± 0,5 kV DC power port (line to line) ± 1 kV signal line (line to earth)	EN 61000-4-5
Interference from high-frequency fields	0.15...80 MHz, 1 V	EN 61000-4-6
Power frequency magnetic field immunity test	Housing: 50/60 Hz, 30 A/m	EN 61000-4-8
Voltage dips, short interruptions, voltage fluctuations	Port: AC mains, level: duration 100 %: 1 cycle and 250 cycles (50 Hz) duration 100 % : 1 cycle and 300 cycles (60 Hz) duration 40 % : 10 cycles (50 Hz) duration 40 %: 12 cycles (60 Hz) duration 70 %: 25 cycles (50 Hz) duration 70 %: 30 cycles (60 Hz) phase: 0°...180°	
Test executed on the 230 VAC side of the power supply		EN 61000-4-11
	Port: DC mains 0 %, duration: 10 ms, 20 fields × 1 s	
Test executed on the 24Vdc of the EUT		EN 61000-4-29

14 Appendix: approvals and markings

Approvals	
DEMKO 20 ATEX 2333X	II 3 G Ex ec IIC T5...T4 Gc
IECEx ULD 20.0001X	Ex ec IIC T5...T4 Gc
Ambient temperature T_{amb} : -20...+60 °C, 0...+50 °C when installed with plug-in module model TX-IO-XX03	
Max. ambient temperature	Temperature Class
-20...+60 °C	T4
0...+50 °C	T5
Approvals	
	see Declarations of conformity (current version)
	
cULus	File No. E484727
	File No. E484803
	Class I, Division 2, Groups A, B, C and D

15 Turck branches — contact data

Germany	Hans Turck GmbH & Co. KG Witzlebenstraße 7, 45472 Mülheim an der Ruhr www.turck.de
Australia	Turck Australia Pty Ltd Building 4, 19-25 Duerdin Street, Notting Hill, 3168 Victoria www.turck.com.au
Austria	Turck GmbH Graumannsgasse 7/A5-1, A-1150 Vienna www.turck.at
Belgium	Turck Multiprox N. V. Lion d'Orweg 12, B-9300 Aalst www.multiprox.be
Brazil	Turck do Brasil Automação Ltda. Rua Anjo Custódio Nr. 42, Jardim Anália Franco, CEP 03358-040 São Paulo www.turck.com.br
Canada	Turck Canada Inc. 140 Duffield Drive, CDN-Markham, Ontario L6G 1B5 www.turck.ca
China	Turck (Tianjin) Sensor Co. Ltd. 18,4th Xinghuazhi Road, Xiqing Economic Development Area, 300381 Tianjin www.turck.com.cn
Czech Republic	TURCK s.r.o. Na Brně 2065, CZ-500 06 Hradec Králové www.turck.cz
France	TURCK BANNER S.A.S. 11 rue de Courtalin Bat C, Magny Le Hongre, F-77703 MARNE LA VALLEE Cedex 4 www.turckbanner.fr
Hungary	TURCK Hungary kft. Árpád fejedelem útja 26-28., Óbuda Gate, 2. em., H-1023 Budapest www.turck.hu
India	TURCK India Automation Pvt. Ltd. 401-403 Aurum Avenue, Survey. No 109 /4, Near Cummins Complex, Baner-Balewadi Link Rd., 411045 Pune - Maharashtra www.turck.co.in
Italy	TURCK BANNER S.R.L. Via San Domenico 5, IT-20008 Bareggio (MI) www.turckbanner.it
Japan	TURCK Japan Corporation ISM Akihabara 1F, 1-24-2, Taito, Taito-ku, 110-0016 Tokyo www.turck.jp

Korea	Turck Korea Co, Ltd. A605, 43, Iljik-ro, Gwangmyeong-si 14353 Gyeonggi-do www.turck.kr
Malaysia	Turck Banner Malaysia Sdn Bhd Unit A-23A-08, Tower A, Pinnacle Petaling Jaya, Jalan Utara C, 46200 Petaling Jaya Selangor www.turckbanner.my
Mexico	Turck Comercial, S. de RL de CV Blvd. Campestre No. 100, Parque Industrial SERVER, C.P. 25350 Arteaga, Coahuila www.turck.com.mx
Netherlands	Turck B. V. Ruiterlaan 7, NL-8019 BN Zwolle www.turck.nl
Poland	TURCK sp.z.o.o. Wroclawska 115, PL-45-836 Opole www.turck.pl
Romania	Turck Automation Romania SRL Str. Siriului nr. 6-8, Sector 1, RO-014354 Bucuresti www.turck.ro
Sweden	Turck AB Fabriksstråket 9, 433 76 Jonsered www.turck.se
Singapore	TURCK BANNER Singapore Pte. Ltd. 25 International Business Park, #04-75/77 (West Wing) German Centre, 609916 Singapore www.turckbanner.sg
South Africa	Turck Banner (Pty) Ltd Boeing Road East, Bedfordview, ZA-2007 Johannesburg www.turckbanner.co.za
Turkey	Turck Otomasyon Ticaret Limited Sirketi Inönü mah. Kayisdagi c., Yesil Konak Evleri No: 178, A Blok D:4, 34755 Kadiköy/ Istanbul www.turck.com.tr
United Kingdom	TURCK BANNER LIMITED Blenheim House, Hurricane Way, GB-SS11 8YT Wickford, Essex www.turckbanner.co.uk
USA	Turck Inc. 3000 Campus Drive, USA-MN 55441 Minneapolis www.turck.us

TURCK

Your Global Automation Partner

Over 30 subsidiaries and
60 representations worldwide!

100048214 | 2025/07



www.turck.com